

OldWood

Oil Classical Varnishes

Classical Amber Varnish - Brescia Brown Varnish - Cremona Varnish – Italian Varnish

Application Instructions

- Professional use -

- 1.- Apply the varnish like any usual oil varnish
- 2.- Only apply on clean and oil-free surfaces.
- 3.- These varnishes can be applied by hand or by brush.
- 4.- In order to obtain the best results thin layers should be applied. To improve the application the varnish can be diluted with OW-Thinner according to your dilution experience.
- 5.- Application of thick layers could provide the contrary expected result and damage the following layers. In this way the drying time will also be increased.
- 6.- Once the product has been applied let the surface dry under direct sunlight or in a UV chamber. It is recommended to check the intensity and the drying time until it has completely dried (a drying time of ± 8 hours is expected but could be different depending on the light intensity and on the thickness applied)
- 7.- Allow 12-24 hours before the next application.
- 8.- A failed drying can provide the contrary expected result and/or surface defaults.
- 9.- The final coat of varnish can be polished with OW Polish and/or Italian Cream, according to the usual oil varnish method. Make sure that the surface has dried properly. Allow extra time before the final polish. .

CAUTION

Wear vinyl or nitril gloves. High humidity or too thick an application may increase drying time. Use in a well-ventilated workspace.

Keep out of the reach of children. Petroleum distillate.

Do not ingest and avoid any contact with skin or eyes. Vapor harmful to skin and respiratory tract. Do not dispose of this product into the environment

Old Wood Colours & Varnishes s.l.

Plaza Castilla, 3 – 28046 Madrid – Spain

www.oldwood1700.com

